



INSTALLATION MANUAL (External)

Planning

- Prepare the area where to install the Perfect Moose.
- Stay organized while connecting to the steam pipe.
- Prepare the Perfect Moose installation kit delivered with your Perfect Moose.



- Prepare the following tools (depending on the steam wand of your espresso machine).



Scissors



Pipe wrench



Protective cloth



Socket wrench No 7

Safety Considerations

- Plan your lift, know what you are moving and where before lifting.
- Perfect Moose works with steam, be aware of the risks.
- Ensure that the mains plug is easily accessible.
- Do not touch the mains plug with wet hands.
- Do not use any mains lead other than that provided with Perfect Moose.



Procedure

- Make sure the steam pipe of your espresso machine is cool and steam supply is turned off.
- Remove the steam nozzle with the wrench using the protective cloth to avoid damage. Depending on your espresso machine you might need an adapter.



- Slide the hose clamp over the steam hose and slide the hose **at least 2 cm** over the steam pipe. Depending on your espresso machine you might need an adapter.





- Tighten the hose clamp with the socket wrench. Stay at least 1 cm from the edge of the steam hose and steam pipe.



- Position your Greg as close as possible to your espresso machine. The shorter the hose the better the micro-foam quality. Never use a hose longer than 1,5m. Cut the hose so there is still enough room to move your Greg. Measure the length of the hose, you will need it in the first start procedure.



- Hold the end of the hose with your Moose Hanky and point it in a safe direction making sure nobody or nothing can get harmed. Carefully and briefly open the steam valve of your espresso machine to evacuate any possible dirt or burr. Attention ! Hot steam will come out of the hose!



- Remove the yellow protection cap from the steam connection at the back of your Greg. Slide the hose clamp over the hose. Slide the hose over the connection piece until it touches the black hose from the Perfect Moose.



- Position the hose clamp over the connection and hose so it stays about 1 cm from the edge. Tighten the hose clamp with your socket wrench n°7 or your PH2 screwdriver.



- Push the drain hose in the connection until you feel it makes a click. Pull gently to check if it's well connected.



- Open the steam valve of your espresso machine and check for leaks.
- Insert the power cord, switch on and let Perfect Moose calibrate. You're ready to start foaming!